

Prosan+ Professional Detergent Chlorine Tablets (1.7g NaDCC)

DESCRIPTION	PRODUCT NO: PN539/PN539P	
<p>Detergent Chlorination Tablets – the safe alternative to sodium hypochlorite (liquid bleach)</p> <p>A fast-dissolving tablet that gives 1,000 parts per million (ppm) available chlorine per litre of water & is combined with an anionic detergent for one-stage cleaning & disinfection.</p> <p>Broad spectrum anti-microbial agent certified to:</p> <ul style="list-style-type: none"> • BS EN1276 - Bactericidal Activity • BS EN1650 - Fungi & Yeast • BS EN13697 - Fungicidal Activity • BS EN13704 - Sporocidal Activity • BS EN13727 - Bactericidal Activity • BS EN14476 - Coronavirus & Norovirus • BS EN16777 - Norovirus • BS EN17126 - C. Difficile <p>*Test data available on request.</p>	<div data-bbox="995 376 1126 510"></div> <div data-bbox="1219 376 1350 510"></div> <p>PN539 Pack Sizes: Unit: 200 Tablets per pot Case: 6 x 200 tablets</p> <p>PN539P Pack Sizes: Unit: 200 Tablets per pouch Case: 6 x 200 tablets</p> <div data-bbox="959 969 1382 1294"></div>	
FEATURES & BENEFITS		
<ul style="list-style-type: none"> • Dual-action cleaning & disinfection tablet producing a detergent, low foaming, free available chlorine solution • Accurate & Measurable Dosing because the dilution system is easy to use, it removes the possibility of over or under-dosing & assists in due diligence • Versatile & Fast Acting – quickly dissolves in water • Easy to Store & Distribute – no risk of leaks, splashes & spillages • Broad Spectrum Kill & Accurate Dosing • For use in: <ul style="list-style-type: none"> • Surface Sanitising post Body Fluid Spills • Disinfecting Toilets, Drains, Sinks, Sluices etc. • Floors, Tiles & Mopping • Disinfecting Non-metallic Medical & Veterinary Appliances & Laboratory Discard Jars • Catering Areas <p>Virtually non-corrosive on most common metals such as Stainless Steel, Aluminium & Galvanised Mild Steel.</p>	<th data-bbox="874 1361 1465 1433">PRODUCT INFORMATION</th> <p>Appearance: White flat bevelled tablet</p> <p>Odour: Characteristic chlorine odour</p> <p>Oxidising: Non-oxidising (by EC criteria)</p> <p>Solubility: Fast dissolving</p> <p>pH: 1 tablet per litre of water: 6 – 6.5</p> <p>Place of Manufacture: UK</p> <p>Export tariff: 3808 942090</p> <p>UFI: C8G1-40QF-Y00F-MU65</p>	PRODUCT INFORMATION

TECHNICAL INFORMATION

Contains: 1.7g Troclosene sodium (NaDCC)
 Tablet Weight: 3.25g
 Tablet Diameter: 18mm
 Chemical Family: Chlorinated S Triazine Trione

Each tablet produces a free available chlorine solution forming predominantly HOCl (hypochlorous acid) sanitiser.

DIRECTIONS

Ensure you are wearing recommended Personal Protective Equipment (PPE) & have the correct equipment required for the task. Take care, solution may bleach fabrics.

See table overleaf for dilution chart

- **Always make a fresh solution every shift or every day (24 hours)**
- **Do not use or mix with other cleaning products as may release dangerous gases (chlorine)**
- **Make solution using potable (tap) water**

General Hard Surfaces, Floors & Wall Disinfection (200ppm), High Risk Hospital Disinfection (1000ppm)

- Clean surface with a neutral detergent first to remove all visible dirt & gross contamination from surface
- If necessary, rinse with hot water & wipe with a clean cloth
- From the dilution table, select the appropriate dilution for the task. Make the required solution strength
- Apply solution to the surface/equipment and leave for the recommended time
- Surface must remain wet for the entire contact time
- If necessary, allow to air dry or use disposable paper towels to dry

Cloth & Mop Soaking (1000ppm)

- After cleaning mops or cloths to remove gross contamination, dissolve 1 tablet in 1 litre of water
- Immerse the cloth or mop in the solution for a maximum of 30 minutes
- Do **not** leave overnight

Food Preparation Surfaces & Food Processing Equipment (500ppm)

- Remove loose debris with a clean, loosely folded cloth
- Wash with a hot neutral detergent solution & cloth. An abrasive nylon pad may also be useful
- Rinse with hot water & a clean cloth
- Drop one detergent chlorine tablet into the recommended amount of water, preferably warm (40°C) to provide 200 ppm of available chlorine
- Thoroughly wet the cleaned surface with the disinfecting solution by the most suitable means, e.g. trigger spray or disposable cloth
- Leave wet for 5 minutes (providing the surface is thoroughly clean this is sufficient contact time for positive disinfection)
- Rinse off with fresh, clean water
- Allow to air dry or use disposable paper towel
- **In the case of dangerous or electrical equipment** (e.g. slicing machines) preliminary safety procedures and final safety checks will be required. Several types of equipment will need partial or complete dismantling to ensure effective cleaning & disinfection

Typical Uses in Private & Public Health Areas

- Cloths & Glassware
- General Disinfection & Hygiene
- Drains, Sinks, WCs & Sluices
- Conditions of Heavy Soiling & Surface Sanitising post Body Fluid Spills
- Veterinary Hygiene

DILUTION TABLE

Prosan+ Detergent Chlorine Tablets
1.7g NaDCC/1,000 parts per million (ppm)

1 TABLET IN: (Clean Potable Water)	GIVES AVAILABLE CHLORINE OF:	TYPICAL USES:	CONTACT TIME:
100ml	10,000 ppm	Contaminated Body Fluid Spills & Conditions of Heavy Soiling (Dirty Conditions)	Minimum 3 minutes
400ml	2,500 ppm	Laboratory Discard Jars	Soak overnight
1 litre	1,000 ppm	General Disinfection in Hospital, Veterinary & Environmental Conditions	5 minutes
1 litre	1,000 ppm	Cloths & Mops	Maximum 30 minutes (do not soak overnight)
1 litre	1,000 ppm	Sporicidal – C.difficile	10 minutes (or 5 minutes for double dose)
2 litres	500 ppm	General Sanitising of Food Equipment & Surfaces	5 minutes
2.5 litres	400 ppm	Toilets, Drains, Sinks, Sluices ect.	15 minutes – pour in quiet periods
5 litres	200 ppm	General Low Risk Surface Cleaning	3 minutes

HEALTH & SAFETY

- **For Professional Use Only!**
- All PPE should comply with appropriate standards & be readily available for use
- In case of an accident refer to the product Safety Data Sheet (SDS) for immediate first aid measures & helpline for a medical emergency

Storage

Store sealed in the original container in a cool, well-ventilated area & away from direct sunlight & extremes of temperature

TOP TIPS

- Warm Water (not hot water) will speed up the tablet dissolution time however final solution should be cool
- When you make up a solution, write on container "date and time"
- Avoid prolonged contact (24 hours plus) with soft metals (eg: Aluminium, Brass, Copper, Gold, Silver etc.)
- Because chlorine solutions using tablets are used at far lower strengths than sodium hypochlorite (liquid bleach), unused solution can be disposed of in Sinks, Toilets, Drains or in a suitable Sluice



Use biocides safely. Always read the label and product information before use.
