

Tel: +44 (0) 1284 810 887 WhatsApp: +44 (0) 7955 005 529 https://www.hygiene4less.co.uk/

GUIDELINES FOR CLEANING ICE CREAM MACHINES

The following guidelines are for ready to serve ice cream making machines.

There are generally, 2 types of machines, self-pasteurising and non self-pasteurising machines. Self-pasteurising type machines periodically re-pasteurise the ice cream mix within the machine, this can effectively extend the period between ice cream making machine cleaning operations.

Cleaning procedure

- 1. Remove all the ice cream from the vessel and dispose of accordingly.
- 2. Fill the hopper with hot water (not boiling or exceeding 38°C or 100°F). Add a <u>neutral detergent</u> to make up wash solution. With the refrigeration switched off, operate the machine for 15-30 seconds to distribute the cleaning solutions.
- 3. Drain the hopper and flush with hot water (not boiling or exceeding 38°C or 100°F). Ensure all ice cream residue has gone or repeat process.
- 4. Remove the components which have come into contact with the ice cream, then wash and soak in a fresh detergent solution (as described in stage 2). Add a <u>PN501 Chlorine Release Tablet</u> to the solution and leave to soak for 2-3 minutes. Before reassembly, rinse the parts in fresh warm water (the drip cup, sump and back seal should be cleaned in this manner).
- 5. The hopper of the machine should be manually washed with a detergent solution (as described in stage 2) and the be rinsed out with warm water. The outside of the machine should be washed with the detergent solution, rinsed off and finally cleaned with a "sterilising" solution.
- 6. To make a "sterilising solution" add 1x chlorine tablet to 5 litres warm water and leave components to soak for a minimum of 3 minutes.
- 7. Finally, reassemble the machine, fill the hopper with the "sterilising solution". Operate the freezer without refrigeration to thoroughly circulate the solution for at least 3 minutes. Drain the solution and thoroughly rinse with warm water before use.

Top Tips

- Train your operator to observe good hygiene practises. Especially ensure Operators wash their hands before dismantling the machine and re-assembly. Unless the operative observes good personal hygiene practices the cleaning process will fail.
- Regular sanitising will prevent long term problems with biofilm build up etc.
- Sanitising takes care and time allow adequate time for the task (typically 30 minutes).
- Milk products can harbour bacteria so take care, store items and components correctly and ensure work area is clean before attempting machine sanitising.
- During operation, use a <u>sanitising wet wipe</u> keep the ice cream dispenser nozzles clean and hygienic.





Tel: +44 (0) 1284 810 887 WhatsApp: +44 (0) 7955 005 529 https://www.hygiene4less.co.uk/

Legal disclaimer: The above information is offered as a guide only and the operator should satisfy themselves as to the effectiveness of the above guidelines and the suitability for their application. The information is believed to be correct but does not purport to be all inclusive and shall be used only as a guide – no warranty or indemnity is implied.

